FGB EGRESS

TOOLS REQUIRED:

Flashlight

APAS Hatch Tool

4" Ratchet Wrench, 1/4" Drive

8mm Deepwell Socket

Air Sample Bottle (one)

Alcohol Pads (for Hatch Seals)

General Purpose Tape, 2"

1. DEACTIVATE NODE 1-FGB VENTILATION

PCS

Node 1: ECLSS: Aft Port IMV Fan

Nod1 Aft Port IMV Fan

'Nod1_ Aft_ Port_IMV_Fan'

sel Fan Commands

cmd Off Execute

√Stat - Off

√Spd,rpm is decreasing

2. FGB AND PMA 1 AIR DUCT DISASSEMBLY

1. TBD

PMA 1

2. Install cap to PMA 1 hard duct inlet. Cover hole with General Purpose Tape.

Secure flat band coupling with over-center latch.

3. Remove cover on hard duct grille assembly.

3. PA-ICC HATCH BULKHEAD RING REMOVAL

PA-ICC Hatch

- 1. Rotate hatch handle in direction of open (OTÊPÜITO) position. Unsecure bottom portion of protective ring alignment pin from socket on handle mechanism assembly.
- 2. Rotate protective ring up to Hatch and detach protective ring brackets from hatch hinge pin.
- Panel 402 3. Fold protective ring and secure to panel using two restraint straps.

4. ALARM CONTROL PANEL DEACTIVATION

1. POWER \rightarrow Off

√Fuse - **(off)**

ICC Port 5. ICC LIGHTING DEACTIVATION

Panel 414

1. 1,2,3,4 E1 (switch) \rightarrow Off (switch down)

ÙÎ-ËÎ

Panel 430

2. 1,2,3,4 E1 (switch) \rightarrow Off (switch down)

ÙÎ-ËÎ

15 MAY 98 1-137 ISS OPS/2A/BAS A

	6.	TAKE AIR SAMPLES OF FGB1. Collect air sample (one) inside the FGB ICC.Stow Air Sample Bottle (one) in "Return to Houston" Bag.	
Orbiter MO10W		CONFIGURE FOR FGB EGRESS 1. 14.7 CAB REG INLET SYS 1,2 vlv (two) → CI	
		2. FGB: ECLSS FGB: ECLSS	
		√FGB Dock Adptr PEV - CI √Nod1 PEV - CI	
ICC	8.	EGRESS FGB ICC 1. √All equipment bags and returning items removed from FGB ICC.	
		 Close FGB PA-ICC Hatch Clean Hatch Seals with Alcohol Pads. Close Hatch. Rotate hatch handle in direction of CLOSE (ÇAÊPÜITÜ) position. 	I
CRT	9.	CONFIGURE FOR PA-IC HATCH LEAK CHECK X: SM 60 TABLE MAINT	
		1. Record CABIN P: psia (FGB ICC closeout press) Use paramid 0612405 psia (hatch delta = 20 mmHg)	
		2. Desired pressure =	I
		3. Record time and FGB ICC pressure:	
		FGB: ECLSS	
		GMT:;: mmHg FGB Cab Press: mmHg	
Orbiter AW82B	10.	FIRST PARTIAL DEPRESS 1. AIRLK DEPRESS vIv cap → Vent, Remove	
		NOTE Klaxon each time airlock depress valve is opened.	
		2. AIRLK DEPRESS vIv \rightarrow 5	
		FGB : ECLSS	

15 MAY 98 1-138 ISS OPS/2A/BAS A

3. √FGB Cab Press not decreasing

Orbiter AW82B		4. When CABIN P = desired pressure from step 9-2 (est. ~3 minute) AIRLK DEPRESS vIv \rightarrow CI
PA Port ÙÎ-ËÎ		PA AND ICC LIGHTING DEACTIVATION 1. 1,2,3,4-Ë1 (switch) → Off (switch down)
PA	12.	EGRESS FGB PA 1. √All equipment bags and returning items removed from FGB PA.
		2. Clean PMA1-PA Hatch Bulkhead Seal with Alcohol Pads.
	13.	CLOSE FGB PMA1-PA HATCH 1. Select 'ĐÀÁÎ ×ÅÅ' (WORKING) torque setting on hatch tool.
		2. Insert tool in hatch socket.
		3. Rotate 3-3.5 turns in direction of 'ÇAÊPÜITÜ' (CLOSE) arrow until it l clicks.
		* If tool prematurely slips or does not engage: * Select 'ÀÂÀĐÉÉÍ Î Å' (EMERGENCY) setting * * on hatch tool. * Reattempt to close Hatch. ***********************************
	14.	CONFIGURE FOR PMA1-PA HATCH LEAK CHECK X: SM 60 TABLE MAINT
		Record CABIN P: psia (FGB PA closeout press) Use paramid 0612405.
		2. Desired pressure = -0.4 psia (hatch delta = 20 mmHg)
		3. Record time and FGB PA pressure: FGB: ECLSS GMT:/::
Orbiter AW82B		SECOND PARTIAL DEPRESS1. Start depress.AIRLK DEPRESS vIv → 5
		FGB: ECLSS
		2. √Docking Adapter Cab Press not decreasing

15 MAY 98 1-139 ISS OPS/2A/BAS A

Orbiter	
AW82B	

3. Stop depress.

When CABIN P = desired pressure from step 14-2 (est. \sim 3.5 minutes) AIRLK DEPRESS vIv \rightarrow CI Install AIRLK DEPRESS vIv cap.

16. NODE 1 PORTABLE FAN CONFIGURATION

NOTE
Location of MRKs in Node 1 is not critical.

Retrieve Portable Fan Assemblies (four) from bag and install Loc-Line Brackets. Position Portable Fan Assemblies equally spaced throughout Node 1.

17. FGB HATCH LEAK CHECK

FGB: ECLSS

1.	At GMT 30 minutes past previous GMT recorded in step 14-3, proceed				
	Record Docking Adapter Cab Press: mmHg				
	Record FGB Cab Press: mmHg				
	GMT:/::				

	* If FGB Cab Press or Docking Adapter Cab *				
	* Press ≤ (pressures recorded in step 9.3 and *				
	* 14.3 ± 2 mmHg) *				
	*				
	* Notify MCC-H.				

2. Report results of leak check to MCC-H.

15 MAY 98 1-140 ISS OPS/2A/BAS A