

## TCS

Advisory:  
NODE1 Htr[X]  
B(A) Failed

### User Notification

PCS NODE 1:  
TCS  
NODE1:  
TCS

sel NODE1  
Htr[X]B(A)

Health Stat - Faild

PCS NODE1:  
TCS  
NODE1:  
TCS

Attention symbol  
appears next to  
NODE1  
Htr[X]B(A)

### Nominal Stage

#### Config:

nav NODE 1: TCS

NODE1: TCS

NODE1 Htr [X]B  
Availbty - Ena Opr

NODE1 Htr [X]A  
Availbty - Ena BU

RPCM N1RS2A  
RPC 1, 2, 3, 4, 12,  
13, 14, 15, 16  
Close Cmd - Enable

RPCM N1RS1A  
RPC 1, 2, 3, 4, 12,  
13, 14, 15, 16  
Close Cmd - Inhibit

### Nominal Assy

#### Config

During Pre-Ingress Warmup, Ingress and Post-Egress Dryout, the heater availability will be variable (limited by power and zone temperature priorities). This procedure accounts for these periods as well as the nominal stage configuration.

## 3A NODE 1 SHELL HEATER FAILURE

1 Check Heater Failure Flags.

PCS NODE 1: TCS  
NODE 1: TCS

- sel NODE1 Htr[X]B(A)
- Determine condition via failure flags:

Availbty - Inh and  
Cmd Stat - On

Hi Lim Violatn - True

Low Lim Violatn - True

No Val Temp Snrsr - True

Temp Snrsr Disagree -  
True

Temp Snsr Stat1(2) - Faild

RPC Position - Op and  
Cmd Stat - On

RPC Position - Cl and  
Cmd Stat - Off

RPC Position - Cl and  
Availbty - Inh

RPC - Trip

82

6

45

2 All B(A) Temp Sensors  
failed?

No

87

Yes

3 Possible loss of MDM  
Card N1-2 A03 (N1-1 A03).

4

- Perform MDM IO CARD FAILURE, all (SODF: C&DH), then
- √MCC-H for heater reconfiguration.

1

1

5 Temp sensor failure.  
No action required.

1

6 Temp(Temp 1 or Temp 2) >  
Temp Snsr(Temp Snsr 1 or  
Temp Snsr 2) Failure Upper  
Limit?

No

7 Transient failure.

8

- Continue nominal operations.

Yes

9

- sel Nod1 Htrs 1-6 (7-9) Availability
- sel Htr[X]B(A) Htr Power

RPC Position - Op?

Yes

10 Possible transient hot  
thermal environment.

2

22

11

- √MCC-H for further action.


1

NCS software will no longer consider this temperature sensor valid. Software will automatically deselect sensor and use the redundant sensor for closed loop control.

2


Failure Upper Limit band may be set too small. MCC-H may uplink a change to Failure Upper Limit.

## 3A NODE 1 SHELL HEATER FAILURE (Cont)




③

The A Heaters are connected to the same RPCM as MDM N1-1. The MDM Failure malfunction will be worked in that case. The B Heaters are not connected to the same RPCM as MDM N1-2; therefore, it is possible that the heater configuration problem could be detected before the RPCM failure.



## 3A NODE 1 SHELL HEATER FAILURE (Cont)





③

The A Heaters are connected to the same RPCM as MDM N1-1. The MDM Failure malfunction will be worked in that case. The B Heaters are not connected to the same RPCM as MDM N1-2, therefore it is possible that the heater configuration problem could be detected before the RPCM failure.

④


**MCC-H** will evaluate the possibility of touch temperature violations and the consequences of leaving the heater on





⑥


Since the RPC has tripped once, it will not be used again unless necessary.



③

The A Heaters are connected to the same RPCM as MDM N1-1. The MDM failure malfunction will be worked in that case. The B Heaters are not connected to the same RPCM as MDM N1-2, therefore it is possible that the heater configuration problem could be detected before the RPCM failure.

## 3A NODE 1 SHELL HEATER FAILURE (Cont)




⑦


Temperature of one sensor is less than its lower setpoint, temperature of the redundant sensor is greater than its upper setpoint. Software will command the heater



## 3A NODE 1 SHELL HEATER FAILURE (Cont)



## 3A NODE 1 SHELL HEATER FAILURE (Cont)



(8)

Temp sensor(s)  
have failed range  
check. Temp  
reading is either  
higher than +400°C  
or lower than  
-350°C. Software  
will command heater  
off (default state).