

## TCS

## PMA 3 SHELL HEATER FAILURE

Advisory:  
PMA3 Htr[X]B(A)  
Faild

### User Notification

PCS NODE 1:  
TCS: PMA3  
PMA3: TCS  
sel PMA3  
Htr[X]B(A) Health  
Stat - Faild

PCS NODE 1:  
TCS: PMA3  
PMA3: TCS  
Attention symbol  
appears next to  
PMA3 Htr[X]B(A)

### Nominal Config:

nav NODE 1: TCS:  
PMA3

PMA3: TCS

PMA3 Htr[X]B  
Availbty - Inh

PMA3 Htr[X]A  
Availbty - Inh

RPCM N1RS2B  
RPC 1, 2, 3, 4, 5,  
12, 13, 14, 15 Close  
Command- Ena

### Nominal Assy Config:

During Pre-Ingress  
Warm-up:


PMA3 Htr[X]B  
Availbty - Ena Opr

PMA3 Htr[X]A  
Availbty - Inh

During Pre-Ingress  
Warm-up:  
PMA3 Htr[X]B  
Availbty - Ena Opr

PMA3 Htr[X]A  
Availbty - Ena BU


RPCM N1RS2B RPC  
Close Command -  
Ena is same for all  
time frames.





①  
The PMA3 Htr A,B designation is for physical redundancy only. Both the A and the B heater strings are controlled by the N1-2 MDM and powered by the N1-RS2 RPCM.

②  
Failure Upper Limit band may be set too small. **MCC-H** may uplink a change to Failure Upper Limit.

## PMA 3 SHELL HEATER FAILURE (Cont)








③

**MCC-H** will evaluate the possibility of touch temperature violations and consequences of leaving the heater on.


④

A transient cold environment could require both B and A heaters to keep temperatures within limits. A heater pad debonding failure could also be the culprit in this case. If all B(A) temperatures do not appear to be rising properly, the failure could be in the EVA cable/connectors P602/J602.




⑤

Since the RPC tripped, it will not be used again unless necessary.



⑥

Since the shell is in a cold condition, the back-up heater should be enabled.



⑦

Temperature sensor has failed its range check. Temperature is either higher than + 400°C or lower than - 350°C. Software will command the heater off (default state).